

## STID Prox Configuration Configuration - Devices Select device & readers

### Mifare Settings

Validation Mode (offline):

Reader type:

Bus Type:

Append number of bits for Wiegand:

Frequency:

MIFARE identifier mode:

© Ignore mode:

\*Ignore Time (sec):

### Prox 125khz Settings

Validation Mode (offline):

Reader type:

Bus Type:

Append number of bits for Wiegand:

Frequency:

© Ignore mode:

\*Ignore Time (sec):

