



Reader A (in) and Reader B (out) is wired the same.

- + - VCC
- - GND
- D1 (L) - DAT
- D0 (S) - CLK

On JCM Connect Set SW1 to on for Wiegand 26

JCM Connect Configuration Configuration - Devices Select device & readers

Reader A

Door_1_A

Validation Mode (offline): Only in archive pass

Reader type: NAL

Bus Type: Wiegand

Append number of bits for Wiegand

Frequency: 125kHz

Ignore mode: Last media (on the same readers)

* Ignore Time (sec): 1

* Comparison Mask:

96969696969696969696969696969696
96969696969696969696969696969696